

BOMBAY[®]

O U T L E T

5503133

O-SCROLL TABLE LAMP


(O-LAMPE DE TABLE ARABESQUES)

Parts list (*Pièces*)

Lamp Base	<i>Pied de lampe</i>	1x
Lamp Shade	<i>Abat-jour</i>	1x
Harp	<i>Lyre</i>	1x
Finial	<i>Faîteau</i>	1x

- * Please make sure that you have all the parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

- * *S'assurer d'avoir toutes les pièces et la quincaillerie énumérées ci-dessus avant de procéder à l'assemblage.*
- * *Cet article doit être assemblé sur une surface lisse afin d'éviter de l'abîmer au cours de l'assemblage.*
- * *Cet article peut nécessiter un resserrement périodique.*



NOTE :

- * This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter plug.
- * Use soft cloth to dust and clean your lamp on a regular basis. Never use chemicals or abrasive cleaner as it may damage the finish on your lamp.
- * Use only the bulb type and wattage indicated on Wattage Label placed on or near socket. NEVER EXCEED MAXIMUM WATTAGE indicated as bulb may cause a fire.

NOTE :

- * *Cette lampe est dotée d'une fiche polarisée (l'une des lames est plus large que l'autre). Pour des raisons de sécurité, la fiche ne s'insère dans la prise que dans un sens. Si la fiche n'entre pas dans la prise, la retourner. S'il est impossible de l'insérer, contacter un électricien. N'utiliser de rallonge seulement si la fiche s'insère parfaitement. Ne pas modifier.*
- * *Nettoyer votre lampe sur une base régulière en utilisant un linge doux. Ne jamais utiliser de produits chimiques ou abrasifs, ils risqueraient d'abîmer le fini de votre lampe.*
- * *Utiliser uniquement le type d'ampoule et la puissance requis tel qu'indiqué sur l'étiquette apposée sur la douille. Afin d'éviter les risques d'incendie, NE JAMAIS EXCÉDER LE WATTAGE MAXIMUM indiqué.*